



4RB – 4ft ~~8ft~~ LED retrofit kit →

5-

5-

- 6- Install supplied screw(s) in slot(s) on both ends and each side of new wireway cover into side of existing channel. For 8' channel also install screw(s) in center side slots
- 7- Turn on power

